



BCS-01W

1D Laser Wireless Barcode Scanner



2. Technical parameters

Product Specification: BCS-01W 1D Laser Wireless Barcode Scanner	
Performance Parameters	
Processor	32-bit MCU
Light Source Type	Visible laser 650nm.
Safely level	National laser safety standard class 1
Transmission	2.4G Wireless and USB Wired
Distance	≤100m
Resolution	4mil
Storage	100000 barcodes
Battery	1500mah
Working time	3 to 5 days
Scanning width	5cm-30cm
Promotion pattern	Buzzer and LED indicator
Scan speed	300 scan/sec
Trigger mode	Handheld,Continuous
Scan angles	Roll35° ; Pitch 75° ; Yaw 65°
Hull material	ABS+PC
Printing Contrast Ratio	≥ 30 %
Decoding capacity	Code 39 Full ASCII, Code 39 TriOptic, Code 128, Code,EAN 128Full ASCII,Codabar,Code93,Discrete2of5,EAN,UPC,ISSN,ISBN,Code25,Codabar,Inteleaved2/5,Interleaved2of5 and China postal service code,etc.
Environmental Parameters	
Power supply mode	DC 5V
Working current	50ma(Operation); 30ma(standby); 100ma(max)
Operating Temperature	0°C to 50°C / 32 to 122°F
Storage Temperature	-20°C to 70°C / -4 to 158°F
Operating humidity	5%-95%(no condensation)
Antistatic ability	15KV Air discharge
Drop test	1.5m
Certificate	CE, FCC, RoHS, IP54

3. Packaging Details

- * Standard List: Scanner *1, Charging Cable *1, USB Receiver *1, Manual *1, Box *1.
- * Single Package Size: 167*80*100mm
- * Single Gross Weight: 0.24kg
- * 50pcs/CTN Carton Size: 535*420*350mm
- * 50pcs/CTN Carton G.W.:13Kg, N.W:12Kg

4. Product Pictures

2-in-1 Connection Ways

Choose the best connection method according to your needs



Powerful Decode Capacity

Excellent decoding ability making scanner more easily to recognizing special barcode



Wide Application



Multiple Keyboard Languages





EU DECLARATION OF CONFORMITY

1. Model No., trademark:

Trademark	POWER ON
Model Name	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW,BCS-04,BCS-05BW

2. Name and address of the manufacturer:

Name of the manufacturer	DOT MEDIA LTD
Address	KATEVASIAS & NTALIAS 18 AXARNAI, GREECE

3. This declaration of conformity is issued under the sole responsibility of the manufacturer.

4. Object of the declaration:

Product Type	Model Name	Sales Name
Barcode Scanner	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW, BCS-04,BCS-05BW	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW, BCS-04,BCS-05BW

5. The object of the declaration described above is in conformity with the relevant Union harmonisation legislation directive and Other Union harmonisation legislation where applicable:

Radio Equipment Directive 2014/53/EU
RoHS Directive

6. References to the relevant harmonised standards or the common specifications used or references to the other technical specifications in relation to which conformity is declared:

Radio Equipment Directive	EN 55032:2015+A11:2020; EN IEC 61000-3-2:2019+A1:2021 EN 61000-3-3:2013+A2:2021; EN 55035: 2017+A11:2020 EN 301 489-1 V2.2.3 (2019-11); EN 301 489-17 V3.2.4 (2020-09) EN 300 328 V2.2.2 (2019-07); EN 62479:2010, EN IEC 62368-1:2020+A11:2020; EN IEC 62680-1-3:2022
RoHS Directive	Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment, 2011/65/EU Annex II and its amendment Directive (EU) 2015/863 as well as RoHS harmonized standard EN IEC 63000: 2018.

7. EU Authorized Representatives Details:

Name: DOT MEDIA LTD

Address: KATEVASIAS & NTALIAS 18 AXARNAI, GREECE

Contact Person: Theodoros Mavroeidis

E-mail: info@dot-media.gr

Place and date of issue

AXARNAI, 20/11/2025

Signature

DOTMEDIA ΕΜΠΟΡΙΑ ΑΝΑΛΩΣΙΜΩΝ ΕΙΔΩΝ
& ΕΦΑΡΜΟΓΩΝ ΠΛΗΡΟΦΟΡΙΚΗΣ ΕΠΕ
ΜΟΝΑΡΧΙΚΟ ΣΥΜΒΟΛΟ ΚΑΙ ΕΠΙΧΕΙΡΗΣΙΑΚΟΥ ΕΞΟΠΛΙΣΜΟΥ
ΚΑΤΕΒΑΣΙΑΣ 18 & ΝΤΑΛΙΑΣ, ΑΧΑΡΝΑΙ, ΕΚ 23671
Α.Φ.Μ.: 999075747 - Δ.Ο.Υ.: ΑΧΑΡΝΩΝ
ΤΗΛ.: 210 2849836, 210 2840486, 210 2849419
FAX: 210 2446835

(Theodoros Mavroeidis)
Technical Manager



ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ ΕΕ

1. Αρ. μοντέλου, εμπορικό σήμα:

Εμπορικό σήμα	POWER ON
Όνομα μοντέλου	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW,BCS-04,BCS-05BW

2. Όνομα και διεύθυνση του κατασκευαστή:

Όνομα του κατασκευαστή	DOT MEDIA LTD
Διεύθυνση	Κατεβάσιας & Ντάλιας 18, Αχαρνές, Ελλάδα

3. Αυτή η δήλωση συμμόρφωσης εκδίδεται με αποκλειστική ευθύνη του κατασκευαστή.

4. Αντικείμενο της δήλωσης:

Τύπος προϊόντος	Όνομα μοντέλου	Όνομα πωλήσεων
Barcode Scanner	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW, BCS-04,BCS-05BW	BCS-01,BCS-01W,BCS-02,BCS-02BW, BCS-03,BCS-03BW, BCS-06BW, BCS-07BW, BCS-04,BCS-05BW

5. Το αντικείμενο της δήλωσης που περιγράφεται παραπάνω είναι σύμφωνο με τη σχετική οδηγία νομοθεσίας εναρμόνισης της Ένωσης και με άλλη νομοθεσία εναρμόνισης της Ένωσης, όπου ισχύει:

Οδηγία 2014/53/ΕΕ για τον ραδιοεξοπλισμό

Οδηγία RoHS

6. Παραπομπές στα σχετικά εναρμονισμένα πρότυπα ή στις κοινές προδιαγραφές που χρησιμοποιούνται ή παραπομπές σε άλλες τεχνικές προδιαγραφές σε σχέση με τις οποίες δηλώνεται η συμμόρφωση:

Οδηγία για τον ραδιοεξοπλισμό	EN 55032:2015+A11:2020; EN IEC 61000-3-2:2019+A1:2021 EN 61000-3-3:2013+A2:2021; EN 55035: 2017+A11:2020 EN 301 489-1 V2.2.3 (2019-11); EN 301 489-17 V3.2.4 (2020-09) EN 300 328 V2.2.2 (2019-07); EN 62479:2010, EN IEC 62368-1:2020+A11:2020; EN IEC 62680-1-3:2022
Οδηγία RoHS	Περιορισμός της χρήσης ορισμένων επικίνδυνων ουσιών σε ηλεκτρικό και ηλεκτρονικό εξοπλισμό, 2011/65/ΕΕ Παράρτημα II και τροποποιητική Οδηγία (ΕΕ) 2015/863 καθώς και εναρμονισμένο πρότυπο RoHS EN IEC 63000: 2018.

7. Στοιχεία εξουσιοδοτημένων αντιπροσώπων της ΕΕ:

Όνομα: DOT MEDIA LTD

Διεύθυνση: Κατεβάσιας & Ντάλιας 18, Αχαρνές, Ελλάδα

Υπεύθυνος επικοινωνίας: Θεόδωρος Μαυροειδής

E-mail: info@dot-media.gr

Τόπος και ημερομηνία έκδοσης

ΑΧΑΡΝΕΣ, 20/11/2025

Υπογραφή

DOTMEDIA ΕΜΠΟΡΙΑ ΑΝΑΛΟΓΙΣΜΩΝ ΕΙΔΩΝ
& ΕΦΑΡΜΟΓΩΝ ΠΛΗΡΟΦΟΡΙΚΗΣ ΕΠΕ
ΚΑΤΕΒΑΣΙΑΣ 18 & ΝΤΑΛΙΑΣ ΑΧΑΡΝΕΣ 23471
Α.Φ.Μ.: 899095747 - Δ.Ο.Υ.: ΑΧΑΡΝΩΝ
ΤΗΛ.: 210 2849836, 210 2840436, 210 2849419
FAX: 210 3446835

Θεόδωρος Μαυροειδής

Τεχνικός Διευθυντής



SKU: BCS-01W

Type: Laser

Barcode Scanner

User Manual

Table of Contents

Restore Defaults	1
Matching Operation(2.4G/433M Mode)	1
Matching Operation(Bluetooth Mode).....	1
Bluetooth Mode Setup	2
IOS Keyboard	2
Bluetooth connection settings.....	2
Working Mode	2
Instant upload Mode.....	2
Storage Mode	2
Transmission speed	3
Trigger Mode.....	4
Power and Standby	4
Buzzer Setup.....	4
End Character.....	5
Capital & Lowercase	5
Duplicate barcode upload Setup.....	5
Barcode Parameter Settings.....	6
Data editing.....	11
Example: Insert character	12
Example: Delete character	13
Appendix 1 : CODE ID	14
Appendix 2: ASCII Barcode Table.....	15
Appendix 3: Language	20

If the scanner does not work or buzzer rang “Di-Di-Di-Di-Di”, please stop using the scanner and charging it immediately.

Restore Defaults

Scanner default setting 2.4G/433M mode, use via USB receiver.

Bluetooth scanner use via bluetooth pairing.

If the scanner does not work properly, Please scan the code “ Restore Defaults”



Restore Defaults

Matching Operation(2.4G/433M Mode)

The scanner with the USB receiver has been paired by default, plug the USB receiver in, and then scan the code “2.4G/433M mode” to use it.

If need to re-pair, please unplug the USB receiver and plug it again, scan sequentially the code “2.4G/433M mode” and “ Match” in 20 seconds.



2.4G/433M Mode



Match

Matching Operation(Bluetooth Mode)

Only to Bluetooth-enabled products

1. Press the button, the buzzer rang, the scanner starts.
2. Scan the “Bluetooth Mode” barcode.
3. Enable bluetooth function on your device till find out “Scanner xxx”, and click it to begin bluetooth pairing. Wait a few seconds, the buzzer rang “ Di--Di”, which means bluetooth pairing is successful.
4. Open a text, put the cursor in, Scan any barcode to see if the barcode can be uploaded.



Bluetooth Mode

Bluetooth Mode Setup



Bluetooth-HID



Bluetooth-SPP



Bluetooth-BLE

IOS Keyboard



Show/hide IOS keyboard

Note: Scan this barcode to show/hide the keyboard in IOS



Show/hide IOS keyboard
double-click -ON*



Show/hide IOS keyboard
double-click -OFF

Bluetooth connection settings



Off connection



Connection initialization

Working Mode

Instant upload Mode

Instant upload data to your computer.



Instant upload Mode

(1) Upload successful: The status light flashed and the buzzer rang “Di ”.

(2) Upload failed: The red light flashed and the buzzer rang “Di---en”.

If you receive upload-failed, Please confirm the match is successful.

If you receive upload-successful but no data, Please confirm the dongle in USB-HID mode.

Storage Mode

Scan and store barcode inside the scanner, and uploaded the data to your computer when you need it.



Storage Mode

Note: Instant upload mode and storage mode, the sound of reading barcode is different.



Show total storage
(Show total number of memory)



Upload Data
(Upload Data to your computer)



Zero clearing
(Clear all data in memory, Please use it with caution)

1. Save successful: The status light flashed and the buzzer rang "Di-en".
2. Save failed: The red light flashed and the buzzer range "Di---en", This indicates that there was not enough memory to save the bar code. Please upload the saved bar code by scanning "Upload Date" and then clear the Memory by scanning "Zero cleaning".
3. Upload completed: the buzzer rang "Di-do-en".

Transmission speed

Set the delay between each character, the range of 00-99 can be set. the larger the value, the slower.



No delay



HID-speed 5



HID-speed 10



HID-speed 15



HID-speed 20



HID-speed 30



HID-speed 40



HID-speed 50



HID-speed 60

1. In 2.4G or 433M mode, this parameter is stored in the dongle and defaults is "No delay". When there is no matching dongle, scanning this setting code is invalid.
2. In Bluetooth mode, this parameter is stored in the scanner, the default is "HID-speed 30".
3. In Bluetooth mode, If the data is lost, please set a slower HID speed.

Trigger Mode

Keys Trigger *	Continuous Mode
Continuous Mode can be used for a long shutdown time or never shut down.	
Auto-sense-OFF	Auto-sense-ON(optional)

Power and Standby



Battery Reserve (show battery level)

Shutdown time setting	
90s	2min*
5min	30min
60min	166min40s
Not shutdown	Shutdown

Buzzer Setup

Turn on all sounds*	Turn off all sounds
Low volume	High volume *

End Character

End character is used to mark the end of a barcode data.



CR *



LF



Tab



CR+LF



None

Capital & Lowercase



Swap capital/lowercase



All lowercase



All capital



Don't convert *

Duplicate barcode upload Setup

For a period of time, the same barcode is not allowed to be read continuously to avoid repeated upload.



Duplicate detection-OFF*
(upload duplicate barcode)



Duplicate detection-ON
(Unable to upload duplicate barcode)

Barcode Parameter Settings

UPCA

 UPCA-ON*	 UPCA-OFF
Check Digit: UPCA data is 12 bits, the 12th bit is the check digit, Default output.	
 Output UPCA check digit-ON*	 Output UPCA check digit-OFF
System character: The first digit of UPCA, Default output.	
 Output UPCA system character-ON*	 Output UPCA system character-OFF
UPCA to EAN13 UPCA to EAN13 by adding a "0" in front of it, and the type is converted to EAN13.	
 UPCA to EAN13-ON	 UPCA to EAN13-OFF*

UPCE

 UPCE-ON*	 UPCE-OFF
Check Digit: UPCE data is 8 bits, the eighth bit is the check digit, Default output.	
 Output UPCE check digit-ON*	 Output UPCE check digit-OFF
System character: The first digit of UPCE, Default output.	
 Output UPCE system character-ON*	 Output UPCE system character-OFF
UPCE to UPCA UPCE can be extended to UPCA, and the type is converted to EAN13.	
 UPCE to UPCA-ON	 UPCE to UPCA-OFF*

EAN13

	
EAN13-ON*	
EAN13-OFF	
Check Digit: EAN13 data is 13 bits, the 13th bit is the check digit, Default output.	
	
Output EAN13 check digit-ON*	
Output EAN13 check digit-OFF	
	
Output EAN13 country code-ON*	
Output EAN13 country code-OFF*	
EAN13 to ISSN/ISBN	
The 977 header is used for ISSN and 978 for ISBN.	
	
EAN13 to ISSN-ON	
EAN13 to ISSN-OFF*	
Set ON, the "977" before the barcode is deleted, and the type is converted to ISSN.	
	
EAN13 to ISBN-ON	
EAN13 to ISBN-OFF*	
Set ON, the "978" before the barcode is deleted, and the type is converted to ISBN.	

EAN8

	
EAN8-ON*	
EAN8-OFF	
Check Digit: EAN8 data is 8 bits, the eighth bit is the check digit, Default output.	
	
Output EAN8 check digit-ON*	
Output EAN8 check digit-OFF	
	
Output EAN8 country code-ON*	
Output EAN8 country code-OFF	

UPC&EAN Extra code

 UPC/EAN extra-code-OFF*	 UPC/EAN 2 Extra-code	 UPC/EAN 5 Extra-code
 UPC/EAN 2/5 Extra-code		 UPC/EAN Must have 2/5 Extra-code

Code39

	
Code39-ON*	Code39-OFF
	
Full-ASCII-OFF*	Full-ASCII-ON
Code39 data can include all ASCII characters, Set ON to read full ASCII characters.	
	
Output Code39 Start/Stop character-OFF*	Output Code39 Start/Stop character-ON
Character * as the Start/Stop character of code 39.	

Code32

Code32 is extended by Code39, When Code32 is enabled, Code39 that complies with Code32 rules will also be output as Code32 first.	
	
Code32-OFF*	Code32-ON
	
Output Code32 check digit-OFF	Output Code32 check digit-ON*
	
Output Code32 Prefix A -OFF	Output Code32 Prefix A -On*

Code128

	
Code128-ON*	Code128-OFF

Code93

	
Code93-ON*	Code93-OFF

Code11

 Code11-ON	 Code11-OFF*
Code11 check digit Code11 barcode data contains check digit, which can be the last 1 (C check) or 2 (CK check) characters of the data.	
 Code11 No check*	 Code11 C/CK check
 Code11 C check	 Code11 CK check
C check: One character check, CK check: Two characters check. No check: Code11 Without check, all check digit will be output. C/CK check: Code11 Automatic C / CK check, all check digits are not output. C check: Code11 perform C check, Do not output 1 check digit, At the same time, the scanner reads only the Code11 by C check. CK check: Code11 perform CK check, Do not output 2 check digits, At the same time, the scanner reads only the Code11 by CK check.	

Codabar

 Codabar-ON*	 Codabar-OFF
CODABAR Start/Stop character Codabar Start/Stop characters are not output by default, When editing the Codabar, you can select the A,B,C,D characters as the Start/Stop characters.	
 Output Codabar Start/Stop character -OFF*	 Output Codabar Start/Stop character -ON
 Output Start/Stop character - allow 1	 Output Start/Stop character - allow 2
allow 1: Start/stop characters are converted from uppercase to lowercase. allow 2: Start characters are converted from uppercase to lowercase, Stop characters changes as follows: A to t, B to n, C to *, D to e.	

Industrial 2 of 5

 Industrial 2 of 5 -ON*	 Industrial 2 of 5 -OFF
---	---

Interleaved 2 of 5

 Interleaved 2 of 5-ON*	 Interleaved 2 of 5-OFF
---	---

MSI

 MSI -ON	 MSI -OFF*
--	--

Pharmacode

 Pharmacode -ON	 Pharmacode -OFF*
---	---

GS1

Contains:GS1 Data Bar, GS1 Data Bar Limited, GS1 Data Bar Expanded.	
 GS1-ON	 GS1-OFF*
GS1 Data Bar check digit GS1 Data Bar : The last bit is check digit.	
 Output GS1 Data Bar check digit -OFF*	 Output GS1 Data Bar check digit -ON
GS1 Data Bar Limited check digit GS1 Data Bar Limited : The last bit is check digit.	
 Output GS1 Limited check digit -OFF*	 Output GS1 Limited check digit -ON

Data editing

Only some product support specified code setting function

 Insert Characters	 Delete characters	
Barcode types(Barcode data: 068000-068018)		
 All barcode types	 UPCE	 UPCA
 EAN8	 EAN13	 ISBN/ISSN
 Code39	 Code128	 Code93
 Codabar	 Interleaved 2 of 5	 industrial 2 of 5
 MSI	 Code11	 China post
 GS1D	 GS1L	 GS1E
 Code32	Do not scan = All barcode types.	
Set save location (Barcode data: 068100-068107) (Different group Settings can take effect at the same time)		
 Group 1	 Group 2	 Group 3
 Group 4	 Group 5	 Group 6
 Group 7	 Group 8	Do not scan = Group 1
Edit location		
 Before barcode	From which place to start? Setup by barcode in "ASCII Barcode Table".	 After barcode
Save to take effect		
 Save Settings	 Clear settings	

Example: Insert character

In the process of setting, scan the irrelevant barcode, the scanner will exit setting status.

Please scan in order 1,2,3, ...

Example: Code128=123456789



	Insert Ab before	Insert Cd from the third	Insert Ef after
1	 Insert Characters		
2	 All barcode types (Omit this step, default all barcode types)		
3	 Group 1 (Omit this step, default Group 1)		
4	 Before barcode	 003 ETX	 After barcode
5	 065 A	 067 C	 069 E
6	 098 b	 100 d	 102 f
	Each group can insert within 10 characters		
7	 Save Settings		
Setup result			
Ab123456789		123Cd456789	123456789Ef
Clear insert character setting, Please scan in order 1,2.		 1, Insert Characters	 2, Clear settings

1, set different bar code type, make this setting to this kind of barcode is effective.

2, set different group, make different Settings take effect at the same time

Example: Delete character

In the process of setting, scan the irrelevant barcode, the scanner will exit setting status.

Please scan in order 1,2,3, ...

Example: Code128=123456789



	Delete 1 bit before	Delete 3 bit from the third	Delete 3 bit after
1	 Delete characters		
2	 All barcode types (Omit this step, default all barcode types)		
3	 Group 1 (Omit this step, default Group 1)		
4	 Before barcode	 003 ETX	 After barcode
5	 001 SOH	 002 STX	 003 ETX
6	 Save Settings		
Setup result			
23456789		1236789	123456
Clear delete character setting, Please scan in order 1,2.		 1, Delete characters	 2, Clear settings

1, set different bar code type, make this setting to this kind of bar code is effective.

2, set different group, make different Settings take effect at the same time.

Appendix 1: CODE ID

 Send ID-OFF *		 Send ID-ON	
Barcode type	Barcode ID	ON/OFF default	Minimum digits
UPCA	b	ON	No
UPCE	c	ON	No
EAN13	e	ON	No
EAN8	d	ON	No
ISBN,ISSN	f	OFF	No
Code39	a	ON	1
Code32	C	OFF	No
Code128	g	ON	2
Code11	M	OFF	4
Code93	h	ON	1
Codabar	k	ON	4
交叉25码	i	ON	4
工业25码	j	ON	4
Pharmacode	P	OFF	2
MSI	I	OFF	4
GS1D	D	OFF	No
GS1L	L	OFF	No
GS1E	E	OFF	No

Appendix 2: ASCII Barcode Table

 000 NUL/SP	 001 SOH	 002 STX
 003 ETX	 004 EOT	 005 ENQ
 006 ACK	 007 BEL	 008 Back Space
 009 HT/TAB	 010 LF	 011 VT
 012 FF	 013 CR/ENTER	 014 SO
 015 SI	 016 DLE	 017 DC1
 018 DC2	 019 DC3	 020 DC4
 021 NAK	 022 SYN	 023 ETB
 024 CAN	 025 EM	 026 SUB
 027 ESC	 028 FS	 029 GS
 030 RS	 031 US	 032 SP
 033 !	 034 "	 035 #
 036 \$	 037 %	 038 &





 039 '	 040 (	 041)
 042 *	 043 +	 044 ,
 045 -	 046 .	 047 /
 048 0	 049 1	 050 2
 051 3	 052 4	 053 5
 054 6	 055 7	 056 8
 057 9	 058 :	 059 ;
 060 <	 061 =	 062 >
 063 ?	 064 @	 065 A
 066 B	 067 C	 068 D
 069 E	 070 F	 071 G
 072 H	 073 I	 074 J
 075 K	 076 L	 077 M

 078 N	 079 O	 080 P
 081 Q	 082 R	 083 S
 084 T	 085 U	 086 V
 087 W	 088 X	 089 Y
 090 Z	 091 [	 092 \
 093]	 094 ^	 095 _
 096 `	 097 a	 098 b
 099 c	 100 d	 101 e
 102 f	 103 g	 104 h
 105 i	 106 j	 107 k
 108 l	 109 m	 110 n
 111 o	 112 p	 113 q
 114 r	 115 s	 116 t

 117 u	 118 v	 119 w
 120 x	 121 y	 122 z
 123 {	 124	 125 }
 126 ~	 127 DEL	 128 F1
 129 F2	 130 F3	 131 F4
 132 F5	 133 F6	 134 F7
 135 F8	 136 F9	 137 F10
 138 F11	 139 F12	 140 I_Shift on
 141 I_Shift off	 142 r_Shift on	 143 r_Shift off
 144 I_Alt on	 145 I_Alt off	 146 r_Alt on
 147 r_Alt off	 148 I_Ctrl on	 149 I_Ctrl off
 150 r_Ctrl on	 151 r_Ctrl off	 152 /(KP)
 153 *(KP)	 154 -(KP)	 155 +(KP)

 156 _(KP)	 157 Enter(KP)	 158 0(KP)
 159 1(KP)	 160 2(KP)	 161 3(KP)
 162 4(KP)	 163 5(KP)	 164 6(KP)
 165 7(KP)	 166 8(KP)	 167 9(KP)
 168 Inert	 169 Delete	 170 Home
 171 End	 172 Page Up	 173 Page Down
 174 Up	 175 Down	 176 Left
 177 Right	 178 Center	 179 Insert
 180 Delete	 181 Home	 182 End
 183 Page Up	 184 Page Down	 185 Up
 186 Down	 187 Left	 188 Right
 189	 190 Num Lock	 191 caps lock
 192 scroll lock		

Appendix 3: Language

 06005000 UNITED STATES	 06005009 FRANCE	 06005018 SERBIA/YUGOSLAVIA
 06005001 BELGIUM	 06005010 GERMANY	 06005019 SLOVENIA
 06005002 BRAZIL	 06005011 HUNGARY	 06005020 SPAIN
 06005003 CANADIAN-FRENCH	 06005012 ITALY	 06005021 SWEDEN
 06005004 CROATIA	 06005013 LATIN AMERICA	 06005022 SWITZERLAND (FRENCH)
 06005005 CZECHOSLOVAKIA (CZECH)	 06005014 NETHERLANDS	 06005023 SWITZERLAND (GERMAN)
 06005006 CZECHOSLOVAKIA (SLOVAK)	 06005015 NORWAY	 06005024 UNITED KINGDOM
 06005007 DENMARK	 06005016 POLAND	 06005025 UNIVERSAL
 06005008 FINLAND	 06005017 PORTUGAL	

Frequently ask question

The bar codes in the user manual are for programming, please don't scan them arbitrarily when no need, otherwise may affect the normal use of the product.

Please try to scan "Restore defaults" bar code in the user manual for a try if the scanner cannot use normally; if problem still not resolve, please try following methods.

Problem 1:

the scanner doesn't have electricity to start on.

Reason:

1. the cable interface loosed, please fixed connection interface.
2. the computer front USB port power supply shortage, please replace the computer interface or change another to try.
3. used the incorrect cables, please use the original cable which the factory is equipped with
4. cable fault, please send back to the factory repair.

Problem 2:

the scanner has laser, but can't read the barcode.

Reason:

1. barcode has flawed, and try to scan the same type barcodes for testing again.
2. the scanning mode is not correct, scanning laser need to completely cover the barcode, if still can't read, please adjust the scanning distance and Angle, the scanner can't read the barcode at 90° angle.
3. the scanner did not open the corresponding code system, it has to scan the barcode after open the corresponding code system.

Problem 3:

the scanner has laser and it can read barcode, but can't upload the data

Reason:

1. The scanner has set up the incorrect output mode, please set the correct output mode refer to the manual.
2. the cable transmission failure, please replace the cable.

Problem 4:

the scanner has laser and it can read barcode. but it uploads the wrong decoding barcode.

Reason: the keyboard layout of the scanner is different with the country you used, please use the scanner to read the keyboard settings on the manual.

If you have any question or concern about the operation of the scanner, please contact us!

SKU: BCS-01W

Producer: Dotmedia ltd

Address: Katevasias & Ntalias 18 Axarnai, Greece

Declaration for EU Hereby, Dotmedia ltd declares that the radio equipment type BCS-01W is in compliance with Directive 2014/30/EU, the full text of the EU declaration of conformity is available at the following internet address: <https://www.dot-media.gr/el/>



**DOTMEDIA LTD, 18 KATEVASIAS str & DALIAS str,
ACHARNES 13671, ATHENS-GREECE.**

