

EDIFIER®

S3300MKII

Active Speaker

Manual Edition 1.0, October 2023
IB-200-S3300MK-II-00

For more information, please visit our website:

www.edifier.com

@Edifierglobal


















































@Edifier_Global

@Edifier_Global

EDIFIER ConnX app

Model: EDF100078
Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong
Tel: +852 2522 6999
Fax: +852 2522 1999
www.edifier.com
© 2023 Edifier International Limited. All rights reserved.
Printed in China

NOTE:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.



www.edifier.com

S3300MKII

Qualcomm aptX HD

Edifier International Limited declares that the radio equipment type EDF10078 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address: <https://www.edifier.com/roa-ds-2023>

FCC ID: 2522-EDF219 IC: 10004-EDF219

Declaration for EU

Frequency Band: 2.402GHz - 2.483GHz

RF Power Output: <10 dBm (ERP)

There is no restriction of use.

EN Power output: L/R (Tweeter) 8W/8W, L/R (Mid-range and bass) 120W/120W Frequency response: 38Hz-40kHz
FR Puissance totale de sortie: GO (Agudo) 8 W/8 W, GO (Medio y bajo) 120 W/120 W Respuesta de frecuencia: 38 Hz-40 kHz
ES Potencia total de salida: GO (Agudo) 8 W/8 W, GO (Medio y bajo) 120 W/120 W Respuesta de frecuencia: 38 Hz-40 kHz
DE Gesamt-Ausgangleistung: GO (Hochton) 8 W/8 W, GO (Mittel- und Tieffrequenz) 120 W/120 W Frequenzgang: 38 Hz-40 kHz
IT Potenza totale di uscita: GO (Alto) 8 W/8 W, GO (Medio e basso) 120 W/120 W Risposta in frequenza: 38 Hz-40 kHz
PT Potência total de saída total: GO (Agudo) 8 W/8 W, GO (Medio e grave) 120 W/120 W Resposta de frequência: 38 Hz-40 kHz
NL Totale uitgangsvermogen: L/R (Hogefrequentie) 8 W/8 W, L/R (Middel en laag) 120 W/120 W Frequentiebereik: 38 Hz-40 kHz
PL Całkowita moc wyjściowa: L/R (wysokie dźwięki) 8 W/8 W, L/R (środkie i niskie) 120 W/120 W Zakres częstotliwości: 38 Hz-40 kHz
CZ Celková výstupní výkonost: L/R (vysoké dźwięky) 8 W/8 W, L/R (střední a nízké) 120 W/120 W Frekvenciová oblast: 38 Hz-40 kHz
SK Celkový výstupní výkon: L/R (vysoké dźwięky) 8 W/8 W, L/R (střední a nízké) 120 W/120 W Frekvenciová oblasť: 38 Hz-40 kHz
SV Totalt utgångsvermogen: L/R (högfrekvens) 8 W/8 W, L/R (mellanfrekvens och lågfrekvens) 120 W/120 W Frekvensområdet: 38 Hz-40 kHz
BG Изходна мощност: L/R (високотон) 8 W/8 W, L/R (среднотон и бас) 120 W/120 W Честотен диапазон: 38 Hz-40 kHz
RO Puterea totală de ieșire: L/R (înaltă frecvență) 8 W/8 W, L/R (gama medie și joasă) 120 W/120 W Răspuns în frecvență: 38 Hz-40 kHz

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN What's in the box?
FR Contenu de la boîte
ES Contenido de la caja
DE Lieferumfang
IT Contenuto della confezione
PT Conteúdo da caixa
NL Wat zit er in de doos?
PL Zawartość pudełka
CZ Co je v krabici?
SK Co je v krabici?
SV Vad finns i boxen?
BG Какво има в кутията?
RO Ce se află în cutie?

EN Source selection
FR Sélection de la source
ES Selección de fuente
DE Quellenauswahl
IT Selezione sorgente
PT Seleção de fonte
NL Bron selectie
PL Wybór źródła
CZ Výběr zdroje
SK Výber zdroja
DK Kildevalg
SV Enkeltvalstycke
BG Избор на източник
RO Selectare sursă

EN Cable connection
FR Connexion par câble
ES Conexión de cable
DE Kabelverbindung
IT Collegamento cavo
PT Conexão via cabo
NL Kabelverbinding
PL Złącze kablowe
CZ Připojení kabelu
SK Káblové pripojenie
SV Kåbelslutning
BG Кабелна връзка
RO Conectare cablu

EN USB connection
FR Connexion USB
PT Conexão USB
NL USB-aansluiting
PL Złącze USB
CZ USB-číslo
SK USB-číslo
SV USB-anslutning
BG USB връзка
RO Conectare USB

EN Control panel
FR Panneau de commande
ES Panel de control
DE Bedienfeld
IT Pannello di controllo
PT Painel de controlo
NL Bedieningspaneel
PL Sterowanie odzwierc
SK Ovládacieho panela
DK Aflyingskontrol
SV Enkeltvalstycke
BG Избор на източник
RO Selectare sursă

EN Standby & wake-up
FR Veille et réactivation
ES Espera y activación
DE Standby & Wecken
IT Standby e riattivazione
PT Espera e despertar
NL Stand-by en wakker worden
PL Tryb gotowości i budzenie
CZ Pohotovostní režim a vzbuzení
SK Pohotovostný režim a vzbudenie
DK Standby og vækning
BG Активност и събуждане
RO Repun la funcționare și scuturare

EN Sound effects
FR Effets sonores
ES Efectos de sonido
DE Soundeffekte
IT Effetti sonori
PT Efeitos sonoros
NL Geluidseffecten
PL Efekty dźwiękowe
CZ Zvukové efekty
SK Zvukové efekty
SV Ljudeffekter
BG Звукови ефекти
RO Efecte sonore

EN Battery replacement
FR Remplacement de la pile
ES Sustitución de batería
DE Batteriewechsel
IT Sostituzione della batteria
PT Substituição de bateria
NL Batterij vervangen
PL Wymiana baterii
CZ Výměna baterie
SK Výmena batérie
DK Udskiftning af batteri
BG Замяна на батерията
RO Înlocuire baterie

EN Bluetooth connection
FR Connexion Bluetooth
ES Conexión Bluetooth
DE Bluetooth-Verbindung
IT Connessione Bluetooth
PT Ligação Bluetooth
NL Bluetooth-verbinding
PL Podłączenie Bluetooth
CZ Připojení Bluetooth
SK Pripojenie k Bluetooth
DK Bluetooth-forbindelse
SV Bluetooth-anslutning
BG Bluetooth връзка
RO Conectare Bluetooth

EN Bluetooth connection
FR Connexion Bluetooth
ES Conexión Bluetooth
DE Bluetooth-Verbindung
IT Connessione Bluetooth
PT Ligação Bluetooth
NL Bluetooth-verbinding
PL Podłączenie Bluetooth
CZ Připojení Bluetooth
SK Pripojenie k Bluetooth
DK Bluetooth-forbindelse
SV Bluetooth-anslutning
BG Bluetooth връзка
RO Conectare Bluetooth

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note:

EN Note:
FR Note:
ES Note:
DE Note:
IT Note:
PT Note:
NL Note:
PL Note:
CZ Note:
SK Note:
SV Note:
BG Note:
RO Note: